



# 北亿纤通科技有限公司

集团旗下

---

# 北亿纤通科技有限公司

集团旗下





| Parameter          | Symbol | Min. | Typical | Max | Unit | Notes |
|--------------------|--------|------|---------|-----|------|-------|
|                    |        |      |         |     |      |       |
| <b>Transmitter</b> |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
| <b>Receiver</b>    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |
|                    |        |      |         |     |      |       |




Figure 1: Interface to Host PCB




Figure 2: Module Contact Assignment

Pin definition



F-tone Networks

# 北亿纤通科技有限公司

集团旗下

---

| Pin | Symbol | Name/Description |
|-----|--------|------------------|
|     |        |                  |

---

北亿纤通科技有限公司




Figure5. Mechanical Specifications

## Regulatory Compliance

| Feature | Agency | Standard |
|---------|--------|----------|
|         |        |          |





F-tone Networks

## Ordering information

| Part Number | Product Description |
|-------------|---------------------|
|             |                     |
|             |                     |

## References

## Important Notice